Handy guide to cleaning symbols



Symbol	Meaning	
Washing		
40	Cotton wash A number in a wash tub without a bar underneath means wash at	
60	the indicated temperature at normal (maximum) washing conditions.	
95		
40	Synthetic wash A number in a wash tub with one bar underneath means wash at	
50	the indicted temperature at medium washing conditions.	
40	Wool wash A number in a wash tub with two bars underneath means wash at the indicated temperature at minimum washing conditions. This is	
	designed for machine washable wool products.	
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Hand wash only You should only wash garments with this symbol by hand	
Bleaching		
\triangle	Any bleach allowed	
\triangle	Use oxygen bleach/ non chlorine bleach only	
*	Do not use bleach	



Handy guide to cleaning symbols



Ironing	
	Hot iron
	Warm iron
	Cool iron
Dry Cleaning	
P	Professional dry clean only.
	The letter in or below the circle tells the dry cleaner which process
F	to use.
w	Professional wet clean only.
X	Do not dry clean
Tumble drying	
	Item may be tumble dried.
<u></u>	Tumble dry with a high heat setting.
O	Tumble dry with a low heat setting.
\boxtimes	Do not tumble dry.
Warning	
X	A cross through any symbol means DO NOT.

